

## Over-Bed Gooseneck Hitches

Make / Model	Style	Years	Footnotes	Folding Ball Hitch#	Fixed Ball Hitch#	Flat Plate Hitch#	Bracket#
<b>Chevrolet</b>							
C1500	8' bed	1988-1999		61052	61100	65500	61503
C2500	8' bed	1988-2000		61052	61100	65500	61503
C3500	8' bed	1988-2000		61052	61100	65500	61503
K1500	8' bed	1988-1999		61052	61100	65500	61503
K2500	8' bed	1988-2000		61052	61100	65500	61503
K3500	8' bed	1988-2000		61052	61100	65500	61503
Silverado 1500	All	1999-2006	Z	61052	61100	65500	61341
Silverado 1500 Classic	All	2007-2007	Z	61052	61100	65500	61341
Silverado 2500	Excluding Cab & Chassis	1999-2004	Z	61052	61100	65500	61341
Silverado 2500 HD	Excluding Cab & Chassis	2011-2019	Z	61052	61100	65500	61301
Silverado 2500 HD	Excluding Cab & Chassis	2001-2010	Z	61052	61100	65500	61341
Silverado 2500 HD Classic	Excluding Cab & Chassis	2007-2007	Z	61052	61100	65500	61341
Silverado 3500	Excluding Cab & Chassis	2001-2006	Z	61052	61100	65500	61341
Silverado 3500 Classic	Excluding Cab & Chassis	2007-2007	Z	61052	61100	65500	61341
Silverado 3500 HD	Excluding Cab & Chassis	2011-2019	Z	61052	61100	65500	61301
Silverado 3500 HD	Excluding Cab & Chassis	2008-2010	Z	61052	61100	65500	61341
<b>Dodge</b>							
Ram 1500	All	1994-2001		61052	61100	65500	61509
Ram 2500	Excluding Cab & Chassis	1994-2002		61052	61100	65500	61509
Ram 3500	Excluding Cab & Chassis	1994-2002		61052	61100	65500	61509
<b>Ford</b>							
F-150	All	1997-2003		61052	61100	65500	61506
F-150	All	1980-1996		61052	61100	65500	61505
F-150 Heritage	All	2004-2004		61052	61100	65500	61506
F-250	Excluding Cab & Chassis	1980-1999		61052	61100	65500	61505
F-250 Super Duty	Over-Bed Gooseneck Installation Brackets	1999-2015	Z	61052	61100	65500	61332
F-350	Excluding Cab & Chassis	1980-1997		61052	61100	65500	61505
F-350 Super Duty	Over-Bed Gooseneck Installation Brackets	1999-2015	Z	61052	61100	65500	61332
F-450 Super Duty	Excluding Cab & Chassis	2008-2011	Z	61052	61100	65500	61332
<b>GMC</b>							
C1500	8' bed	1988-1999		61052	61100	65500	61503
C2500	8' bed	1988-2000		61052	61100	65500	61503
C3500	8' bed	1988-2000		61052	61100	65500	61503
K1500	8' bed	1988-1999		61052	61100	65500	61503
K2500	8' bed	1988-2000		61052	61100	65500	61503
K3500	8' bed	1988-2000		61052	61100	65500	61503
Sierra 1500	All	1999-2006	Z	61052	61100	65500	61341
Sierra 1500 Classic	All	2007-2007	Z	61052	61100	65500	61341
Sierra 2500	Excluding Cab & Chassis	1999-2004	Z	61052	61100	65500	61341
Sierra 2500 HD	Excluding Cab & Chassis	2011-2019	Z	61052	61100	65500	61301
Sierra 2500 HD	Excluding Cab & Chassis	2001-2010	Z	61052	61100	65500	61341
Sierra 2500 HD Classic	Excluding Cab & Chassis	2007-2007	Z	61052	61100	65500	61341
Sierra 3500	Excluding Cab & Chassis	2001-2006	Z	61052	61100	65500	61341
Sierra 3500 Classic	Excluding Cab & Chassis	2007-2007	Z	61052	61100	65500	61341
Sierra 3500 HD	Excluding Cab & Chassis	2011-2019	Z	61052	61100	65500	61301
Sierra 3500 HD	Excluding Cab & Chassis	2007-2010	Z	61052	61100	65500	61341

### Footnotes

Z - No frame drilling required